

WHACK A CROCK - TICKET CONTROL

PCB

1ST TICKET Then 1 TICKET EVERY

0	10
10	20
20	30
30	40
40	
50	
60	
70	
80	

DIP SWITCH

1ST TICKET	2	3	4	5	6	7
0	ON	ON	ON	ON		
10	OFF	ON	ON	ON		
20	ON	OFF	ON	ON		
30	OFF	OFF	ON	ON		
40	ON	ON	OFF	ON		
50	OFF	ON	OFF	ON		
60	ON	OFF	OFF	ON		
70	OFF	OFF	OFF	ON		
80	ON	ON	ON	OFF		

Thereafter every 10 ON ON

20	OFF	ON
30	ON	OFF
40	OFF	OFF

WHACK-A-CROCK

4042
ADDED TO DISPLAY PANEL



